

IMPORTANT

BATEAU BATH (LA ROCHELLE'S/COPPERS/BIARITTZ) CARE GUIDE

Installation Guide

 We recommend applying a bead of silicon to the underside of the skirt of the bath in order to prevent movement and rocking on any high spots on the floor. On applying the sealant, the bath will need to be weighted down. However, if choosing to weigh the bath down with water, <u>water should NOT be left in the</u> <u>bath following the application of silicon as this can leave water marks around the bath. Instead, weigh</u> <u>the bath down with books, etc.</u>

With minimum care and attention, your bath will give you many years of luxurious enjoyment. To keep your bath looking good then you should:

- rinse it thoroughly after use to avoid a build-up of soap scum;
- dry the bath after use with a soft cloth or towel; this will avoid any water marks or **limescale build up** and is especially important if you live in a **HARD WATER** area;
- ensure that you fix any dripping taps as this will mark the enamel/tin over time;
- clean the bath surface regularly with a soft cloth and a non-abrasive and non-acidic cleaner
- La Rochelle's with a polished exterior, as well as Cyprium Copper baths with a lacquered copper exterior, should be cleaned with a non-acidic window cleaner and a soft cloth.

Our Copper Baths are hand-made products and will have an imperfect finish to both the tin exterior/interior and copper exterior. This can include ripples to the surface, and areas of darkened tin. These imperfections will have no impact on the function or longevity of the bath.



If you have any queries then please do not hesitate to contact us on **01723 585896** or email <u>sales@castironbath.co.uk</u>

The Cast Iron Bath Company Ltd, Aurora House, Hopper Hill Road, Eastfield, Scarborough, North Yorkshire, YO11 3YS